

FUTURERETRO

ORB RACKMOUNT INSTALLATION INSTRUCTIONS

This document describes the procedure for installing 3 Orb sequencers within a standard 19" rack enclosure. Enclosed in your Orb rackmount kit you should find 2 rack ears, 2 unit rails, and 12 Phillips screws.

The first step to installing the rack kit is to remove the existing desktop side panels on each of the 3 Orb units. Simply remove the 2 black Phillips screws holding each side panel on the unit. Keep these screws, as we will use them later on.

Next, remove the 2 black Phillips screws located on the bottom rear of each Orb unit. Set the 3 Orb units on their back surface (each unit side by side) so you have easy access to these screw locations. Take one of the unit rails and align the holes in the rail to the screw hole locations on the Orb. Notice the unit rail is "L"-shaped, and you want the flat portion of the rail without holes pointing away from the bottom of the unit and closest to the back edge of the unit. Now you can install 6 of the 12 Phillips screws securing the rail to the unit. It's best if you start with mounting the middle unit first, then mounting the 2 outer units. Make sure the units are mounted evenly.

Next remove the 2 black Phillips screws located at the bottom front of each Orb unit. Take the remaining unit rail and align it with these screw hole locations on the Orb. Again the flat portion of the rail without holes should point away from the bottom of the unit and be closest to the front edge of the unit. Now install the remaining 6 Phillips screws securing the rail to the unit. Once the units are evenly aligned, be sure to tighten all 12 screws securing the rails to the unit.

Finally you're ready to install the rack ears on the two outer Orb units. Align the rack ears so the small portion with holes faces towards the front of the unit. Use 2 of the Phillips screws you removed earlier from the desktop pieces, and install them so the rack ears are fastened to the sides of the two outermost Orb units.

When you are complete, your units should look like the images below (front and back view). Be sure to keep all remaining screws and end pieces in case you wish to convert the Orb units back to desktop versions in the future.

